
Model WR503 Drill Press Depth Gauge

Wixey"


The WR503 can be mounted to a variety of drill presses in a number of different ways. Pick the mounting method and position that works best for your machine.


If your drill press has a conventional depth stop rod the scale can be attached to that (FIG 1). If you don't have a depth stop rod it can be attached directly to the collar on the quill (FIG 2).

NOTE: The Scale can be carefully cut shorter using a hack saw if it is too long (FIG 3)




There 2 different brackets provided to mount the readout to a depth stop rod and they can be mounted in several different ways. Directly in front of the depth stop using the **Stop Bracket** (FIG 4) or off to the side using the **Offset Bracket** (FIG 5)







When attaching to the collar on the quill, use the **Quill Bracket** and **Hose Clamp** as shown in FIG 6 and FIG 7




The **Scale** is attached to all the brackets in the same way (FIG 8)





Center-punch the screw locations and use the 3.6mm drill bit and the M4 x 8mm long thread forming screws to attach the **Headstock Bracket** to the drill press (FIG 10). Put a drop of oil on the end of the screws and use a nut driver to force the screws into the holes while turning slowly.






Attach the **Headstock Bracket** to the back of the display as shown in FIG 9 and find a suitable location to mount it to the side of the drill press.







For more info on this and other Wixey products visit: www.wixey.com