


## SAFETY FIRST

- Always turn off and unplug power tools before using the Digital Protractor
- Never use your power tools without properly installed blade guards. The guards may not be shown in our instructions only to make the illustrations clear.




### ON/OFF

- Short press to turn on or off the display only
- Press and hold 3 sec. to shut down completely
- Auto shut off after 6 minutes (display only)
- Moving the arms turns the display on unless shut down


### ZERO

- Press at any position to set display to 000.0

### Setting to 000.0 with the arms folded flat together



### Setting to 000.0 with the arms opened up flat



# Wixey®

Model WR 41BT

## SMART PROTRACTOR w/Bluetooth®

### Battery Installation



Push on the tab to expose the battery holder



Pull the holder completely out of the protractor



Insert a CR2032 battery into the holder with the plus side down



Re-install the holder



Friction knob tightens or loosens the arms